



SAF-T PURGE 200 Hot Melt Purging Compound General Instructions for Adhesive Equipment

1. Stir well before using.
2. Drain system of all hot melt adhesive.
3. Add R-1744 to pot, heat to a temperature between 350°F and 400° F. Turn pump on and circulate for a minimum of 30 minutes. Drain compound from the system completely and discard material.
4. Add hot melt adhesive and discard the first few minutes.

The above instructions are for cleaning your equipment or changing from one adhesive to another.

SAF-T PURGE 200 can be used with EVA, polyolefin, acrylic, and rubber base adhesives.

*****SAF-T PURGE 200 is never to be used near open flames.*****

Disclaimer of Warranties:

Premier Packaging Solutions LLC. expressly disclaims all warranties, either expressed or implied, including any implied warranty of merchantability, fitness for a particular purpose or from course of dealing or usage of trade.